Geothermal energy




Learning outcomes of todays lecture

- Geothermal energy:
 - Know the intrinsic geothermal heat flux and average geothermal heat gradient
 - Explain the 'renewable' character of geothermal heat
 - Know different geothermal systems (for power)
 (dry vs. hydro-reservoirs; dry steam flash process binary cycle)
 - Explain and calculate 1st law (energy) and 2nd law (exergy) efficiency for geothermal systems
 - Know different geothermal systems for heat applications



Earth's subsurface temperatures




Zone	Distance from surface [kr	m] Temperature [° C]	Density [kg/dm3]
Ground	0		
Crust (bottom)	35	1100	3.3
Mantle (bottom)	2900	3700 to 4500	5.7 to 10.2
Liquid (iron) core	5100	4300 to 6000	11.5
Solid inner (iron) core	6350	4500 to 6600	11.5

average gradient 30 K/km

2000 Geothermal Education Office



Temperature gradient in the Earth's crust (K/km)



→ the <u>sustainable</u> intrinsic geothermal heat flux is very low!



Geothermal potential (world)

- The average geothermal heat flux is approximately 50 60 mW/m², resulting from:
 - The flux from the hot Earth interior (= residual heat from the Earth's origin; tidal friction)
 - In the crust (0 to 50 km), radioactive decay (40K, U, Th)
- Worldwide: 50 mW/m² → multiplied with area of the 5 continents (135 Mkm²) => 6.75 TW_{heat}
 - Assuming 20% electrical efficiency and 8000 h load:
 - => 1.35 TW_{el} and 11'000 TWh_{el} (= 50% of current world electrical production) but exploiting *every square meter* of land on the planet!
- Geothermal energy can only deliver a small contribution worldwide (on the order of ≈1 %), and it has to come from <u>local anomalies</u>



Geothermal heat flux


• USA / Europe

SMU Geothermal Laboratory Heat Flow Map of the Conterminous United States, 2011

**The Content of the Conterminous United States, 2011

**The Content of the Content of th

Switzerland





Geothermal potential (Switzerland)

- For Switzerland: 65 mW/m² → with area 41'000 km² => 2.67 GW_{heat} or 84 PJ assuming 20% electrical efficiency and 8000 h/yr load, max. deliver 4 TWh_{el} from 500 Mw_{el} (again when collecting this heat flux *from every square meter*!)
- This compares to the yearly Swiss electrical need of 60 TWh_{el} from ca. 25 GW_{el} installed power, or to the yearly present heating needs of ca. 430 PJ
- Taking population density of 200 people / km², which is 5000 m² per person, it follows that 65 mW/m² * 5000 m² = 325 W_{heat} / person → 65 W_{el} / person (20%) (compare to total electrical end-consumption = 850 W_{el} per person and 1300 W_{thermal} end-use per person for space heating + hot water)
- The intrinsic geothermal heat flux is too low
- We can extract much more heat from the underground, but then we are not operating in a sustainable fashion




Geothermal reality – Power production


- 14 GW_{el} supplied worldwide
- Iceland gets 30% of its electricity from geothermal, has only 300'000 inhabitants
- The USA is number 1 and has 2.587 GW_{el} installed geopower, which produces 16 TWh_{el}, but this is only 0.3% of the USA electricity
- Countries around the Pacific 'Ring of Fire' can provide a significant share of their needs from geo-energy


Country	Power [GW]	% of elec.			
USA	2.587	0.3			
Philippines	1.928	27			
Indonesia	2.131	3.7			
Turkey	1.613	0.3			
Mexico	0.906	3			
Italy	0.797	1.5			
NZ	0.984	14.5			
Iceland	0.756	30			
Japan	0.525	0.1			
El Salvador	0.204	14			
Kenya	0.824	38			
Costa Rica	0.262	14			
Nicaragua	0.153	9.9			
World	14	0.3			
> 85 TWh.					



Geothermal reality – Power production










Occurrence – Locations – the 'Ring of Fire'





Distribution of geothermal plants





Italy (Tuscany) as pioneer

1st plant worldwide,1911, in Larderello

- 200°C at 1 km depth; max 437°C at 3.2 km
- 1 W/m² heat flux; ca. 200 km² active area
- 160-250 °C, superheated steam 4-20 bar
- avgerage flux 25 t/h (7 kg/s), max 350 t/h
- 790 MW_{el}, >5.5 TWh_{el}; 10% of world's geopower










Some general features of geothermal power

Example:



Extract power for 10 MW plant: we allow cooling from 250°C to 200°C

For heat transfer fluid water:
$$P=10MW=\dot{V}$$
 $\stackrel{1000kg/m^3}{\tilde{p}}$ $\stackrel{4186J/kgK}{\tilde{c}_p}$ $\stackrel{200-40^{\circ}C}{\tilde{\Delta T}} \rightarrow \dot{V}=15~l/s$ Heat available in ground (assume rock, cooled to 200°C): $Q_{avail}=V$ $\stackrel{\rho}{\rho}$ $\stackrel{C_p}{c_p}$ $\stackrel{\Delta T}{\Delta T}=6.5\cdot 10^{13}~J$

Rock is cooled to 200°C in: $t = \frac{Q}{P} = 75 \ day$

Recharge by conduction:

Heat flow:
$$Q = A \frac{\Delta T}{\Delta x} k = \frac{Q_{avail}}{\Delta t} \rightarrow \Delta t = 20 \ years$$

Can be unsustainable!

- heat extraction rate >> geothermal heat flux => the soil is cooled down (v.v. slowly)
- power production must last min. 25 years (and can last up to centuries) so as to justify the investment
- Time lapse from discovery to production can be long too
 - e.g. Miravalles (Costa Rica) discovered in 1976 but first power generated in 1994
- Baseload power (renewable; independent from season or climate)
- Geothermal water/steam = 'free fuel'
- Borehole drilling is very expensive
 - the technology exists from hydrocarbon reservoirs exploration (oil, gas), which can afford a few failed drillings, as the reward from fossil fuel (unlike geothermal 'fuel') is very high!



Classification of geothermal systems

They are related to young **igneous rock*** intrusions in the upper earth crust


- Magma
- Hot <u>dry</u> rock (HDR)
- Convective <u>hydrothermal</u> reservoirs ('<u>wet</u>')
 - vapor dominated
 - liquid dominated

exploitation in geothermal power plants



^{*} Igneous rock is one of the 3 main rock types, formed through the cooling and solidification of magma or lava. (The other 2 are sedimentary and metamorphic rock.)

Hydrothermal reservoirs






Classification of hydrothermal reservoirs

Characteristic	Temperature	Depth - Location	Plant type
'low-T' water	100°C-150°C	< 3 km 50 K / km selected sites	Binary, ORC
'high-T' water	150°C – 370°C	< 2 km >100 K / km anomalous sites	Flash
vapor	>200°C	< 2 km Larderello,	Dry steam




Different forms





Temperature level usage



United States in the 21st century, MIT technical report, 2006




Binary fluid

Electric Generation

Electricity production potential

Thermodynamics:

- Hot source (geothermal resource)
- Cold source (river or ambient air)



Maximum available power (exergy):

$$\dot{Ex} = \left(1 - \frac{T_0}{T_h}\right) \dot{Q}_{in}$$
Carnot factor

$$\eta = rac{\dot{W}_{cycle}}{\dot{Q}_{in}}$$

Electrical efficiency – Energy

no account for T levels (energy quantity)

$$\varepsilon = \frac{W_{cycle}}{\left(1 - \frac{T_0}{T_h}\right)\dot{Q}_{in}}$$

Exergy efficiency - Exergy accounts for T levels (energy quality)



Determination of the hot source 'average' temperature

- 'Logarithmic mean temperature' <u>difference</u>' of heat <u>exchange</u> (HEX)
- Heat exchange between a hot fluid, cooling from $T_{h,in}$ to $T_{h,out}$, and a cold fluid, warming from $T_{c,in}$ to $T_{c,out}$, learns us that

$$LMTD = \frac{(T_{h,1} - T_{c,1}) - (T_{h,2} - T_{c,2})}{\ln \left[\frac{T_{h,1} - T_{c,1}}{T_{h,2} - T_{c,2}} \right]} \quad \text{and the transferred heat:}$$

$$Q = U \cdot A \cdot LMTD$$

with U = heat transfer coefficient (W/m 2 ·K) and A = HEX area (m 2)

The geothermal reservoir is not a constant temperature hot source;

heat is extracted at $T_{h,in}$ and reinjected at $T_{h,out}$;


the average hot source temperature T_h

is then determined from its logarithmic mean:

$$LMT = \frac{\left(T_{h, in} - T_{h, out}\right)}{\ln \left|\frac{T_{h, in}}{T_{h, out}}\right|}$$



Logarithmic mean temperature





Electricity production: energy vs exergy efficiency

Geothermal power plant of Soultz-sous-Forêts (Alsace, F):

Pilot project for electricity from EGS exploitation at 5000m



Gross electricity production: 2.1 MW_{el}

Parasitic losses: 0.6 MW_{el}

Net electricity production: 1.5 MW_{el}

Carnot factor =
$$1 - (T_a/LMT) = 1 - 288/393 = 0.28$$

Leda Gerber, LENI

• T at well:
$$175^{\circ}$$
 C $(=T_{h,in})$ $(LMT_h=120^{\circ}$ C)

• T reinjection: 70° C (=T_{h out})

• Flow rate: **35 l/s** (take T_a as 15° C)

$$\Rightarrow$$
 Heat flux Q = massflow * Cp * Δ T = 35 (kg/s) * 4184 (J/kg.K) * 105 (K) =

$$\dot{Q}_{in} \approx 15.4 MW_{th}$$

$$\eta = \frac{\dot{W}_{cycle}}{\dot{Q}_{in}} = 10\%$$

1st Law: low efficiency!

$$\eta = \frac{\dot{W}_{cycle}}{\dot{Q}_{in}} = 10\% \qquad \varepsilon = \frac{W_{cycle}}{\left(1 - \frac{T_0}{T_h}\right)\dot{Q}_{in}} = 35\%$$

2nd Law: comparable to thermal power plants



Importance of T-level

2 liquid resources with 50 kg/s, $T_a = 10 \, ^{\circ}$ C, same $\Delta T = 50$ K:


Leda Gerber, LENI

$$T_{h,in} = 200^{\circ} \text{ C}$$
 $T_{h,in} = 150^{\circ} \text{ C}$ $T_{h,out} = 100^{\circ} \text{ C}$ $T_{h,out} = 100^{\circ} \text{ C}$ $Q^{+} = \dot{m} \cdot c_{p} \cdot (T_{in} - T_{out}) = 10500 \ kW_{th}$ $C_{p}(H_{2}O)=4184 \ J/kg/K$ $C_{arnot} = 1 - \frac{T_{a}}{factor}$ 0.288 max. electricity: 3864 kWe T_{h} max. electricity: 3024 kWe T_{h}



Electricity production potential as f(T)

Leda Gerber, LENI



20% = typical 1st law effectiveness




Geothermal plant, aerial view



Ronald DiPippo: Geothermal power plants: Elsevier 2008




Geothermal plant, closer view



Ronald DiPippo: Geothermal power plants: Elsevier 2008




Wellhead view




Ronald DiPippo: Geothermal power plants: Elsevier 2008



Turbine rotor (110 MW)








Hatchobaru plant, Japan



Ronald DiPippo: Geothermal power plants: Elsevier 2008



Cerro Prieto (720 MW), Baja California (Mexico)






Ronald DiPippo: Geothermal power plants: Elsevier 2008

Dry steam power plant

• Steam (no water) shoots up the wells directly into a turbine. Dry steam fields are *rare*.



2000 Geothermal Education Office




Dry steam power plant

• The Geysers dry steam field, northern California, the 1st USA geothermal power plant (1962) and still the world's largest (1 GW_{el} average).





Dry steam power plant





Flash steam plant


• Flash technology was invented in New Zealand. Flash steam plants are the most common, since most reservoirs are hot (pressurized) water reservoirs.





Flash steam power plant


 As hot water is released from the high pressure of the deep reservoir in a flash tank, some of it (30-40%) flashes explosively to steam.





Flash conversion cycles

- Direct use of the geofluid (=liquid, or mixture of gas and liquid)
- Separation between liquid and gas (power from steam turbine)
- Temperature lower limit: 150-180 °C
- Quality of the geofluid is critical (dissolved minerals!)




Single-flash system


Double-flash system Additional power generation More expensive




Single-flash schematics

silencer (S)
cyclone separator (CS)
ball check valve (BCV)
water piping (WP)
steam ejector/condenser (SE/C)











Double-flash schematics






Ronald DiPippo: Geothermal power plants: Elsevier 2008




Example of turbine for two-phase expansion






Direct expansion from saturated liquid: biphase ("total flow") turbine






Total flow expander





Flash Binary Plant, Upper Mahiao (125 MWe)




Ronald DiPippo: Geothermal power plants: Elsevier 2008



Binary cycle power plant

Heat from the geothermal water is used to vaporize a working fluid in a 2nd network.
 This vapor powers the turbine.




2000 Geothermal Education Office



Binary conversion cycles

- Heat transfer occurs between the geofluid and a secondary fluid
- Use of organic fluids (Organic Rankine cycles ORC) or mixture of water and ammonia (Kalina cycles)
- Temperature lower limit: 70-90°C (uses exist up to 200°C)
- No emissions of geofluid to atmosphere






Combined conversion cycles

To increase the electrical efficiency

Flash system with bottoming ORC






Leda Gerber, LENI

Cogeneration with conversion cycles


Effects on energy and exergy efficiency

- Increase due to the use of waste heat (flash systems)
- Trade-off between electricity and heat production (binary cycles)






Hot <u>dry</u> rock (HDR) – or Deep Heat <u>Mining</u> (DHM)






- 1. Injection well
- 2. Fissured rock
- 3. Production well
- 4. Control wells
- 5. Pump
- 6. HEX
- 7. Plant
- 8. District heat




HDR, Hijiori, Japan






Temperature level usage



•J. Tester et al, The Future of Geothermal Energy – Impact of Enhanced Geothermal Systems (EGS) on the United States in the 21st century, MIT technical report, 2006






Geothermal reality – Heat

28% Direct heat use 72% Heat pumps

40% Direct heat use 60% Heat pumps







Figure 10: Installed capacity [MW] of all geothermal heat uses (direct use and GHP use) in member countries and worldwide 2000 - 2017. Member country data: IEA Geothermal Annual Reports 2007, 2008 and 2009, and WG 10 country reports 2010 to 2017; world data: Lund & Freeston, 2001; Lund et al., 2005 and 2011; and Lund & Boyd, 2016; 2015-2017: estimated assuming a compound annual growth rate of 7.9%.

Figure 11: Annual heat use [GWh/a] of all geothermal heat uses (direct use and GHP use) in member countries and worldwide 2000 - 2017. Member country data: IEA Geothermal Annual Reports 2007, 2008 and 2009, and WG 10 country reports 2010 to 2017; world data: Lund & Freeston, 2001; Lund et al., 2005 and 2011; and Lund & Boyd, 2016; 2015-2017: estimated assuming a compound annual growth rate of 6.9%.

Direct heat use: district or space heating, bathing, heating of greenhouses, snow melting, aquaculture/fish farming or industrial applications, etc.



Different forms






Close to surface

• Residential application with heat pump (80% of Swiss geothermal energy use):


Geothermal heat probe

- 1 Heat pump
- Floor heating
- E Heat exchanger (double U-tube)
- Bore hole (<20 cm diameter)</p>



Geothermal heat basket

- Heat pump
- Floor heating
- Geothermal baskets



Depth:


1.5 to 4 m for geothermal baskets50 to 250 m for heat probe

Temperature: 5-20°C



Heat pump systems


Vapor-compression heat pumps:






Close to surface

• Year around:





- Temperature for geothermal baskets between 7 and 13°C all year
- Phase lag results in warmest temperature in November (→largest heating demand)
- Cooling possibilities in summer



Intermediate depths

From:

- Thermal springs (natural springs)
- Tunnels (groundwater)
- Hydrothermal (aquifers), depth 0.5-3 km

Temperature range: 20-100 °C

Use:

- Thermal baths, swimming pools
- Industry: drying, evaporation of concentrated solutions, chemical extraction, deicing (streets)
- Agriculture: drying, green hoses, fish farms

In 2015: 75 TWh thermal energy used in direct applications



the tropical house in Frutigen (BE) uses the warm water from the Lötschberg tunnel for breeding sturgeons and cultivating exotic fruits



Klamath Falls, Oregon, a geothermal district-heating system keeps the sidewalks clear and dry at the Basin Transit station after a snowfall

Geothermally powered greenhouses at Gufudalur, Hveragerði



Summary

- Geothermal power plants are clean, reliable and provide **baseload** for decades or centuries, on sites with *thermal anomalies* (volcanic, tectonic).
- Elsewhere, smaller individual plants may be used (1-5 MWe)
- Usually, steam cycles are employed; to exploit <u>low temperature</u> reservoirs for electricity generation, <u>ORCs</u> can be used
- 1st law efficiency is rather poor (<20%) but 2nd law efficiency high (>50%)
- Exploitation for thermal energy interesting and more widely used

